

FITTING INSTRUCTIONS



Pack Includes

Heavy duty barrel spring base 680mm fiberglass whip (full antenna height 962mm) 14.5m Low-loss coaxial cable, pre-terminated FME connector and PL259 adaptor

IMPORTANT - Always fit in accordance with State Road & Traffic Safety Guidelines

Installation

1. Install the spring base onto the bracket (not supplied). Tighten in a clockwise direction using a hexagon wrench or spanner. IMPORTANT: Do not exceed 50N.

For a full range of Oricom brackets visit: oricom.com.au



2. Install the fiberglass whip to the elevated feed by turning in a clockwise direction and hand tighten only MAX. 15N.